# MR F57W



## CLASS-D FIXED MOUNT VHF RADIO

The latest in Class-D Digital Selective Calling (DSC) Technology.

#### **Submersible**

Designed to IPX8 (JIS8) standards.

## Rewind-Say-Again®

Replay missed VHF calls. Automatically records the last 20 seconds with a digital voice recorder.

### **PA Output**

PA function for public address to external speaker.

#### All NOAA weather channels

Instant access to national All Hazards and weather information, 24 hours a day.

## **Softkey Operation**

Easily make calls, activate advance features and navigate through menus.

#### **Automatic Radio Check**

Checks battery voltage when transmitting, RF power output, and antenna output.

#### Flush mount kit included

Everything you need for quick and easy install.





DSC (Digital Selective Calling)  Compliant with the latest FCC specifications for Class-D VHF Radios. Digital Selective Calling allows you to send a distress signal at the touch of a button or exchange position information with other boats or stations. DSC features on this Class-D radio include; A Dedicated Channel 70 (DSC Channel) Receiver, GPS Position Display Capability, Illuminated Distress Button, Easy MMSI Entry, Position Send and Request, Position Display Capability, Illuminated Distress Button, Easy MMSI Entry, Position Send and Request, Position Input Reminder, Coast Guard DSC Check Capability, etc.  1 or 25 Watts  Dual output power for short and long communication.  U.S.A., Canada & International Channels  Allows operation on any of the three (3) different channel maps established for these areas.  Rewind-Say-Again®  Replay missed calls. Automatically records the last 20 seconds of incoming radio transmissions. Handy when in noisy conditions.  10 NOAA Weather Channels  Instant access to national all hazards and weather information, 24 hours a day.  Weather Alert  Alerts with an audible tone and visual alarm if threatening weather is nearby.  Automatic Radio Check  Checks battery voltage when transmitting, RF power output, and antenna output.  Instant Channel 16/9  Instant access to channel 16 and channel 9 for emergency situations.  GPS Capability  Plug-and-Play using the new C.P.S. (Cobra Positioning Systems) external GPS. No other connections required. You can send your position information in case of emergency, or exchange position information with other boats.  TriWatch  Monitors three (3) channels at once - Channel 16, Channel 9, and one (1) user selected channel.  Scan / Memory Scan  Scan all channels to find conversations in progress, or scan channels placed into memory.  Channel Names  Friendly WHF channel names under the channel number.  Signal Strength Meter  Shows the strength of incoming signal.  Illuminated LCD Display: Large  Allows high visibility of keys.  MEA in and Out  NMEA in or GP	Features	Benefits	
U.S.A., Canada & International Channels   Allows operation on any of the three (3) different channel maps established for these areas.   Rewind-Say-Again®   Replay missed calls. Automatically records the last 20 seconds of incoming radio transmissions.   Handy when in noisy conditions.	DSC (Digital Selective Calling)	allows you to send a distress signal at the touch of a button or exchange position information with other boats or stations. DSC features on this Class-D radio include; A Dedicated Channel 70 (DSC Channel) Receiver, GPS Position Display Capability, Illuminated Distress Button, Easy MMSI	
Rewind-Say-Again® Replay missed calls. Automatically records the last 20 seconds of incoming radio transmissions. Handy when in noisy conditions.  10 NOAA Weather Channels Instant access to national all hazards and weather information, 24 hours a day.  Weather Alert Alert Alerts with an audible tone and visual alarm if threatening weather is nearby.  Automatic Radio Check Checks battery voltage when transmitting, RF power output, and antenna output.  Instant Channel 16/9 Instant access to channel 16 and channel 9 for emergency situations.  GPS Capability Plug-and-Play using the new C.P.S. (Cobra Positioning Systems) external GPS. No other connections required. You can send your position information in case of emergency, or exchange position information with other boats.  TriWatch Monitors three (3) channels at once - Channel 16, Channel 9, and one (1) user selected channel.  Scan / Memory Scan Scan all channels to find conversations in progress, or scan channels placed into memory.  Channel Names Friendly VHF channel names under the channel number.  Signal Strength Meter Shows the strength of incoming signal.  Illuminated Keys Allows high visibility of keys.  Illuminated LCD Display: Large Allows high visibility of display.  Noise Canceling Microphone Blocks background noise.  External Speaker and PA Speaker Connect an external speaker and a PA (Public Address) speaker.  NMEA in for GPS input. NMEA output to display other vessels and their information transmitted by DSC on your chartplotter.  Submersible Meets JIS8 standards; Submersible for 30 minutes in one meter deep water.  External Alarm Input Senses the alarm from your chartplotter and uses the speaker on the radio to amplify the alam for waypoint arrival, MOB, etc.	1 or 25 Watts	Dual output power for short and long communication.	
Haindý when in noisy conditions.  10 NOAA Weather Channels  Instant access to national all hazards and weather information, 24 hours a day.  Weather Alert  Alerts with an audible tone and visual alarm if threatening weather is nearby.  Automatic Radio Check  Checks battery voltage when transmitting, RF power output, and antenna output.  Instant Channel 16/9  Instant access to channel 16 and channel 9 for emergency situations.  GPS Capability  Plug-and-Play using the new C.P.S. (Cobra Positioning Systems) external GPS. No other connections required. You can send your position information in case of emergency, or exchange position information with other boats.  TriWatch  Monitors three (3) channels at once - Channel 16, Channel 9, and one (1) user selected channel.  Scan / Memory Scan  Scan all channels to find conversations in progress, or scan channels placed into memory.  Channel Names  Friendly VHF channel names under the channel number.  Signal Strength Meter  Shows the strength of incoming signal.  Illuminated Keys  Allows high visibility of keys.  Illuminated LCD Display: Large  Allows high visibility of display.  Noise Canceling Microphone  Blocks background noise.  External Speaker and PA Speaker  Connect an external speaker and a PA (Public Address) speaker.  NMEA in and Out  NMEA in for GPS input. NMEA output to display other vessels and their information transmitted by DSC on your chartplotter.  Submersible  Meets JIS8 standards; Submersible for 30 minutes in one meter deep water.  External Alarm Input  Senses the alarm from your chartplotter and uses the speaker on the radio to amplify the alam for waypoint arrival, MOB, etc.	U.S.A., Canada & International Channels	Allows operation on any of the three (3) different channel maps established for these areas.	
Meather Alert Alerts with an audible tone and visual alarm if threatening weather is nearby.  Checks battery voltage when transmitting, RF power output, and antenna output.  Instant Channel 16/9 Instant access to channel 16 and channel 9 for emergency situations.  GPS Capability Plug-and-Play using the new C.P.S. (Cobra Positioning Systems) external GPS. No other connections required. You can send your position information in case of emergency, or exchange position information with other boats.  TriWatch Monitors three (3) channels at once - Channel 16, Channel 9, and one (1) user selected channel.  Scan / Memory Scan Scan all channels to find conversations in progress, or scan channels placed into memory.  Channel Names Friendly VHF channel names under the channel number.  Signal Strength Meter Shows the strength of incoming signal.  Illuminated Keys Allows high visibility of keys.  Illuminated LCD Display: Large Allows high visibility of display.  Noise Canceling Microphone Blocks background noise.  External Speaker and PA Speaker Connect an external speaker and a PA (Public Address) speaker.  NMEA in and Out NMEA in for GPS input. NMEA output to display other vessels and their information transmitted by DSC on your chartplotter.  Submersible Meets JIS8 standards; Submersible for 30 minutes in one meter deep water.  External Alarm Input Senses the alarm from your chartplotter and uses the speaker on the radio to amplify the alam for waypoint arrival, MOB, etc.	Rewind-Say-Again®	Replay missed calls. Automatically records the last 20 seconds of incoming radio transmissions. Handy when in noisy conditions.	
Automatic Radio Check Checks battery voltage when transmitting, RF power output, and antenna output.  Instant Channel 16/9 Instant access to channel 16 and channel 9 for emergency situations.  GPS Capability Plug-and-Play using the new C.P.S. (Cobra Positioning Systems) external GPS. No other connections required. You can send your position information in case of emergency, or exchange position information with other boats.  TriWatch Monitors three (3) channels at once - Channel 16, Channel 9, and one (1) user selected channel.  Scan / Memory Scan Scan all channels to find conversations in progress, or scan channels placed into memory.  Channel Names Friendly VHF channel names under the channel number.  Signal Strength Meter Shows the strength of incoming signal.  Illuminated Keys Allows high visibility of keys.  Illuminated LCD Display: Large Allows high visibility of display.  Noise Canceling Microphone Blocks background noise.  External Speaker and PA Speaker Connect an external speaker and a PA (Public Address) speaker.  NMEA in and Out NMEA in for GPS input. NMEA output to display other vessels and their information transmitted by DSC on your chartplotter.  Submersible Meets JIS8 standards; Submersible for 30 minutes in one meter deep water.  External Alarm Input Senses the alarm from your chartplotter and uses the speaker on the radio to amplify the alam for waypoint arrival, MOB, etc.	10 NOAA Weather Channels	Instant access to national all hazards and weather information, 24 hours a day.	
Instant Channel 16/9 Instant access to channel 16 and channel 9 for emergency situations.  Plug-and-Play using the new C.P.S. (Cobra Positioning Systems) external GPS. No other connections required. You can send your position information in case of emergency, or exchange position information with other boats.  TriWatch Monitors three (3) channels at once - Channel 16, Channel 9, and one (1) user selected channel.  Scan / Memory Scan Scan all channels to find conversations in progress, or scan channels placed into memory.  Channel Names Friendly VHF channel names under the channel number.  Signal Strength Meter Shows the strength of incoming signal.  Illuminated Keys Allows high visibility of keys.  Illuminated LCD Display: Large Allows high visibility of display.  Noise Canceling Microphone Blocks background noise.  External Speaker and PA Speaker Connect an external speaker and a PA (Public Address) speaker.  NMEA In and Out NMEA in for GPS input. NMEA output to display other vessels and their information transmitted by DSC on your chartplotter.  Submersible Meets JIS8 standards; Submersible for 30 minutes in one meter deep water.  External Alarm Input Senses the alarm from your chartplotter and uses the speaker on the radio to amplify the alam for waypoint arrival, MOB, etc.	Weather Alert	Alerts with an audible tone and visual alarm if threatening weather is nearby.	
GPS Capability  Plug-and-Play using the new C.P.S. (Cobra Positioning Systems) external GPS. No other connections required. You can send your position information in case of emergency, or exchange position information with other boats.  TriWatch  Monitors three (3) channels at once - Channel 16, Channel 9, and one (1) user selected channel.  Scan / Memory Scan  Scan all channels to find conversations in progress, or scan channels placed into memory.  Channel Names  Friendly VHF channel names under the channel number.  Signal Strength Meter  Shows the strength of incoming signal.  Illuminated Keys  Allows high visibility of keys.  Illuminated LCD Display: Large  Allows high visibility of display.  Noise Canceling Microphone  Blocks background noise.  External Speaker and PA Speaker  Connect an external speaker and a PA (Public Address) speaker.  NMEA in and Out  NMEA in for GPS input. NMEA output to display other vessels and their information transmitted by DSC on your chartplotter.  Submersible  Meets JIS8 standards; Submersible for 30 minutes in one meter deep water.  External Alarm Input  Senses the alarm from your chartplotter and uses the speaker on the radio to amplify the alam for waypoint arrival, MOB, etc.	Automatic Radio Check	Checks battery voltage when transmitting, RF power output, and antenna output.	
connections required. You can send your position information in case of emergency, or exchange position information with other boats.  TriWatch Monitors three (3) channels at once - Channel 16, Channel 9, and one (1) user selected channel.  Scan / Memory Scan Scan all channels to find conversations in progress, or scan channels placed into memory.  Channel Names Friendly VHF channel names under the channel number.  Signal Strength Meter Shows the strength of incoming signal.  Illuminated Keys Allows high visibility of keys.  Illuminated LCD Display: Large Allows high visibility of display.  Noise Canceling Microphone Blocks background noise.  External Speaker and PA Speaker Connect an external speaker and a PA (Public Address) speaker.  NMEA in for GPS input. NMEA output to display other vessels and their information transmitted by DSC on your chartplotter.  Submersible Meets JIS8 standards; Submersible for 30 minutes in one meter deep water.  External Alarm Input Senses the alarm from your chartplotter and uses the speaker on the radio to amplify the alam for waypoint arrival, MOB, etc.	Instant Channel 16/9	Instant access to channel 16 and channel 9 for emergency situations.	
Scan / Memory Scan Scan all channels to find conversations in progress, or scan channels placed into memory.  Channel Names Friendly VHF channel names under the channel number.  Signal Strength Meter Shows the strength of incoming signal.  Illuminated Keys Allows high visibility of keys.  Illuminated LCD Display: Large Allows high visibility of display.  Noise Canceling Microphone Blocks background noise.  External Speaker and PA Speaker Connect an external speaker and a PA (Public Address) speaker.  NMEA In and Out NMEA in for GPS input. NMEA output to display other vessels and their information transmitted by DSC on your chartplotter.  Submersible Meets JIS8 standards; Submersible for 30 minutes in one meter deep water.  External Alarm Input Senses the alarm from your chartplotter and uses the speaker on the radio to amplify the alam for waypoint arrival, MOB, etc.	GPS Capability	connections required. You can send your position information in case of emergency, or exchange	
Channel Names Friendly VHF channel names under the channel number.  Signal Strength Meter Shows the strength of incoming signal.  Illuminated Keys Allows high visibility of keys.  Illuminated LCD Display: Large Allows high visibility of display.  Noise Canceling Microphone Blocks background noise.  External Speaker and PA Speaker Connect an external speaker and a PA (Public Address) speaker.  NMEA In and Out NMEA in for GPS input. NMEA output to display other vessels and their information transmitted by DSC on your chartplotter.  Submersible Meets JIS8 standards; Submersible for 30 minutes in one meter deep water.  External Alarm Input Senses the alarm from your chartplotter and uses the speaker on the radio to amplify the alam for waypoint arrival, MOB, etc.	TriWatch	Monitors three (3) channels at once - Channel 16, Channel 9, and one (1) user selected channel.	
Signal Strength Meter Shows the strength of incoming signal.  Illuminated Keys Allows high visibility of keys.  Illuminated LCD Display: Large Allows high visibility of display.  Noise Canceling Microphone Blocks background noise.  External Speaker and PA Speaker Connect an external speaker and a PA (Public Address) speaker.  NMEA In and Out NMEA in for GPS input. NMEA output to display other vessels and their information transmitted by DSC on your chartplotter.  Submersible Meets JIS8 standards; Submersible for 30 minutes in one meter deep water.  External Alarm Input Senses the alarm from your chartplotter and uses the speaker on the radio to amplify the alam for waypoint arrival, MOB, etc.	Scan / Memory Scan	Scan all channels to find conversations in progress, or scan channels placed into memory.	
Illuminated Keys Allows high visibility of keys.  Illuminated LCD Display: Large Allows high visibility of display.  Noise Canceling Microphone Blocks background noise.  External Speaker and PA Speaker Connect an external speaker and a PA (Public Address) speaker.  NMEA In and Out NMEA in for GPS input. NMEA output to display other vessels and their information transmitted by DSC on your chartplotter.  Submersible Meets JIS8 standards; Submersible for 30 minutes in one meter deep water.  External Alarm Input Senses the alarm from your chartplotter and uses the speaker on the radio to amplify the alam for waypoint arrival, MOB, etc.	Channel Names	Friendly VHF channel names under the channel number.	
Illuminated LCD Display: Large Allows high visibility of display.  Noise Canceling Microphone Blocks background noise.  External Speaker and PA Speaker Connect an external speaker and a PA (Public Address) speaker.  NMEA In and Out NMEA in for GPS input. NMEA output to display other vessels and their information transmitted by DSC on your chartplotter.  Submersible Meets JIS8 standards; Submersible for 30 minutes in one meter deep water.  External Alarm Input Senses the alarm from your chartplotter and uses the speaker on the radio to amplify the alam for waypoint arrival, MOB, etc.	Signal Strength Meter	Shows the strength of incoming signal.	
Noise Canceling MicrophoneBlocks background noise.External Speaker and PA SpeakerConnect an external speaker and a PA (Public Address) speaker.NMEA In and OutNMEA in for GPS input. NMEA output to display other vessels and their information transmitted by DSC on your chartplotter.SubmersibleMeets JIS8 standards; Submersible for 30 minutes in one meter deep water.External Alarm InputSenses the alarm from your chartplotter and uses the speaker on the radio to amplify the alam for waypoint arrival, MOB, etc.	Illuminated Keys	Allows high visibility of keys.	
External Speaker and PA Speaker  Connect an external speaker and a PA (Public Address) speaker.  NMEA In and Out  NMEA in for GPS input. NMEA output to display other vessels and their information transmitted by DSC on your chartplotter.  Submersible  Meets JIS8 standards; Submersible for 30 minutes in one meter deep water.  External Alarm Input  Senses the alarm from your chartplotter and uses the speaker on the radio to amplify the alam for waypoint arrival, MOB, etc.	Illuminated LCD Display: Large	Allows high visibility of display.	
NMEA in and Out  NMEA in for GPS input. NMEA output to display other vessels and their information transmitted by DSC on your chartplotter.  Submersible  Meets JIS8 standards; Submersible for 30 minutes in one meter deep water.  External Alarm Input  Senses the alarm from your chartplotter and uses the speaker on the radio to amplify the alam for waypoint arrival, MOB, etc.	Noise Canceling Microphone	Blocks background noise.	
by DSC on your chartplotter.  Submersible Meets JIS8 standards; Submersible for 30 minutes in one meter deep water.  External Alarm Input Senses the alarm from your chartplotter and uses the speaker on the radio to amplify the alam for waypoint arrival, MOB, etc.	External Speaker and PA Speaker	Connect an external speaker and a PA (Public Address) speaker.	
External Alarm Input  Senses the alarm from your chartplotter and uses the speaker on the radio to amplify the alam for waypoint arrival, MOB, etc.	NMEA In and Out		
for waypoint arrival, MÓB, etc.	Submersible	Meets JIS8 standards; Submersible for 30 minutes in one meter deep water.	
3 Year Warranty (on radio) For products sold in the U.S.A.	External Alarm Input		
	3 Year Warranty (on radio)	For products sold in the U.S.A.	

#### **Included Accessories**

Flush & Surface Mount Kit	Easy installation of radio in or on almost any flat surface.
GPS Interface Cable	Allows connection of a GPS receiver or NMEA 0183 devices.



Cobra®, CobraMarine®, Nothing Comes Close to a Cobra®, and the snake design are registered trademarks of Cobra Electronics Corporation, USA. Cobra Electronics Corporation™ is a trademark of Cobra Electronics Corporation, USA.

©2014 Cobra Electronics Corporation, 6500 West Cortland Street, Chicago, IL 60707, USA

# **Unit Specifications General**

Number of Channels	All: U.S.A., Canadian, International 10 NOAA Weather Channels
Channel Spacing	25 kHZ
Modulation	5 kHz Max.
Input Voltage	13.8 VDC
Current Drain: Stand-by	200 mA
Receive	300 mA
Transmit	5 A @ High Power 1 A @ Low Power
Temperature Range	-20°C to 60°C
Unit Dimensions	6.25" x 2.25" x 7.125" (159 mm x 57 mm x 180 mm)
Unit Weight (Lbs)	2 lbs., 6.8 oz. (1100 g)

#### Receiver

Frequency Range	156.050 to 163.275 MHz
Receiver Type	Double Conversion Super-Heterodyne
Sensitivity: 20 dB Quieting	0.35 uV
12 dB Sinad	0.30 uV
AF Output	4 Watts @ 8 Ohms

#### **Transmitter**

Frequency Range	156.025 to 157.425 MHz
RF Output Power	1 or 25 Watts
Spurious Emissions	-75 dB @ High Power -72 dB @ Low Power
Microphone Type	Electret
Microphone Impedance	2000 Ohms
Frequency Stability	+/-10 ppm
FM Hum & Noise	50 dB

#### **Packaging Specifications**

Individual Clam/Box Dimensions	3.25"H x 12.60"W x 9.70" D
Individual Clam/Box Weight	3.7 lbs.
Master Pack Qty.	2
Master Pack Dimensions	9.80"H x 13.80"W x 8.10"D
Master Pack Weight	9.40 lbs.
SKU # (White)	MR F57W
UPC #	0 28377 20181 3
Master Pack Barcode	5 0028377 20181 8
SKU # (Black)	MR F57B
UPC #	0 28377 20186 8
Master Pack Barcode	5 0028377 20186 3

Specifications subject to change without notice.

